

30
160
I/O
PWR
DL OUT
1 Reserve
2 UART1 TXD
3 UART1 RXD
4 Reset
5 GND
6 Amp En / Dis
7 Reserve
8 Reserve
9 Reserve
REMOVAL
DEBUG
DAL1946-65ALP
170
DL IN